# Lab 11

MAC address Table

# Lab Objective:

Learn how a switch populates its MAC table in order to quickly forward frames out of the correct interface.

# Lab Purpose:


When switches boot, they have no directory of which MAC addresses are connected to which interface. As traffic enters the port, the switch adds the source MAC address to a MAC address table so it doesn't have to broadcast for the address next time.

## Lab Tool:

**Packet Tracer** 

## Lab Topology:

Please use the following topology to complete this lab exercise:



# Lab Walkthrough:

## Task 1:

Connect four hosts to a Cisco switch using straightthrough cables.


### Task 2:

Check the MAC address table on the switch. It should be empty at the moment:

| Switch#show mac-address-table |
|-------------------------------|
| Mac Address Table             |
|                               |
| Vlan Mac Address Type Ports   |
| Switch#                       |

#### Task 3:

Allocate IP addresses to the hosts from within the subnet 192.168.1.0. Here is how I did it on the first PC. You can use 192.168.1.1, then 192.168.1.2, and so on.



#### Task 4:

From one of the PCs ping the other three. Below, I am on host 192.168.1.1, and ping hosts .2, .3, and then .4

```
Communit Principle

C:\>ping 192.168.1.2

Pinging 192.168.1.2 with 32 bytes of data:

Reply from 192.168.1.2: bytes-32 time<lms TTL-128

Reply from 192.168.1.2: bytes-32 time<lms TTL-128

Reply from 192.168.1.2: bytes-32 time<lms TTL-128

Reply from 192.168.1.2: bytes-32 time=lms TTL-128

Reply from 192.168.1.2: bytes-32 time=lms TTL-128

Ping statistics for 192.168.1.2:

Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),

Approximate round trip times in milli-seconds:

Minimum = 0ms, Maximum = 1ms, Average = 0ms

C:\>ping 192.168.1.3

Pinging 192.168.1.3 with 32 bytes of data:

Reply from 192.168.1.3: bytes-32 time=lms TTL-128

Reply from 192.168.1.3: bytes-32 time=lms TTL-128

Reply from 192.168.1.3: bytes-32 time-lms TTL-128

Ping statistics for 192.168.1.3:

Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),

Approximate round trip times in milli-seconds:

Minimum = 0ms, Maximum = 1ms, Average = 0ms

C:\>ping 192.168.1.4


Pinging 192.168.1.4 with 32 bytes of data:

Reply from 192.168.1.4 bytes-32 time=lms TTL-128

Reply from 192.168.1.4: bytes-32 time=lms TTL-128

Ping statistics for 192.168.1.4:
```

Task 5: Check the MAC address table on the switch once more.



You can go ahead and check the MAC address on your host to ensure the one in the switch MAC address table is correct.

